

CAMERALINK

# Wirelessly connect your camera to SlingStudio.

Use your HDMI camera or camcorder to wirelessly send video to SlingStudio.<sup>™</sup> CameraLink gives you professional-quality content by sending up to 1080p60 video at up to 30 Mbps using H.264 encoding.

**VIDEO & AUDIO INPUT** 



HDMI and Digital Audio	1 HDMI Type D connector supporting 1080p60, 1080i60, 1080p30, 720p60, and 720p30 video inputs
	2-channel HDMI embedded audio (48 KHz, 44.1 KHz, 36 KHz, 16-bit)
STREAMING FORMAT	
Video Encoding	H.264 High Profile 4:2:0 1080p60 up to 30 Mbps 1080p30 up to 16 Mbps 720p60 up to 16 Mbps 720p30 up to 4 Mbps
Audio Encoding	AAC-LC at 320 kb/s 2-channel 48 KHz, 16-bit
Compatibility	Supported* cameras and camcorders with an HDMI output for wirelessly sending video and audio to SlingStudio
	*Concurrented devices at MuclingStudia cam/commetibility

\*See supported devices at MySlingStudio.com/compatibility.

#### **BATTERY & CHARGING**

Battery Life	2+ hours	2+ hours		
Battery Charging	Micro-USB charging port fo	Micro-USB charging port for use with common smartphone/tablet USB cables		
Charging Time	3 to 4 hours when CameraLi	3 to 4 hours when CameraLink is off using a USB cable with 10 W (5V, 2A) or higher		
HARDWARE				
Wireless	802.11ac – used to transmi to SlingStudio	802.11ac – used to transmit encoded video from camera/camcorder to SlingStudio		
Interfaces	1080i60, 1080p30, 720p60,	HDMI Type D input supporting both interlaced and progressive formats (1080p60, 1080i60, 1080p30, 720p60, 720p30) Micro-USB input (for charging via USB)		
LED Indicators	4 battery status LEDs 1 Micro-USB charging LED 1 power status LED 1 program tally LED			
LED Behaviors	Power Status LED			
	Status	Meaning		
	<u>Status</u> Off	Meaning Power-off state		
	Off	Power-off state		
	Off Blinking Red	Power-off state Pairing (WPS) mode		
	Off Blinking Red Solid White Blinking White and Program Tally LED is	Power-off state Pairing (WPS) mode Connected to SlingStudio		
	Off Blinking Red Solid White Blinking White and Program Tally LED is Blinking White Blinking White and	Power-off state Pairing (WPS) mode Connected to SlingStudio Powering on		
	Off Blinking Red Solid White Blinking White and Program Tally LED is Blinking White Blinking White and	Power-off state Pairing (WPS) mode Connected to SlingStudio Powering on Powered on and looking to connect to SlingStudio		
	Off Blinking Red Solid White Blinking White and Program Tally LED is Blinking White Blinking White and Program Tally LED is Off	Power-off state Pairing (WPS) mode Connected to SlingStudio Powering on Powered on and looking to connect to SlingStudio Program Tally LED		

Power Button Functions	Status	Action
	On	Press and hold for 3 seconds
	Pairing (WPS) Mode	Press and hold for 10 seconds in a powered-on
		state
	Off	Press and hold for 3 seconds

#### **Physical Attributes**

Size: (H) 1.38" x (W) 4.56" x (D) 2.87" / (H) 35 mm x (W) 115.8 mm x (D) 72.8 mm Weight: 0.6 lbs (270 g)

Lithium-ion 3.7 V, 3100 mAH battery

CameraLink

Battery

MySlingStudio.com/CameraLink



## HARDWARE (CONT.)

Operating Temperature	32°F to 95°F (0° to 35°C)
Humidity	0 to 95% (non-condensing)

### ACCESSORIES

In the Box	Hot shoe mount Micro-USB cable HDMI Type D-to-HDMI Type C cable
Sold Separately	HDMI Type D-to-HDMI Type A cable HDMI Type D-to-HDMI Type D cable